

here are the MIDIjet Pro DSSS frequencies

Chan	Freq
0	2402MHz
1	2405
2	2408
3	2411
4	2414
5	2417
6	2420
7	2423
8	2426
9	2429
10	2432
11	2435
12	2438
13	2441
14	2444
15	2447
16	2450
17	2453
18	2455
19	2457
20	2459
21	2461
22	2463
23	2465
24	2467
25	2469
26	2471
27	2473
28	2475
29	2477
30	2479